


Supplementary figure S1



Supplementary figure S1: Capillaries were analysed by MATLAB script

Opening each green channel picture in Image J and splitting them into the grayscale (B). this picture will be analyzed by the MATLAB script which automatically generates 4 images, including the original image (A), the binary image with different colors (C), the histograms of the area data and perimeter data (D and E). The MATLAB script also automatically generates two excel sheets with number, area (μm^2) and perimeter (μm) of the capillaries for further analysis by Graphpad software. The MATLAB script was set at a require value (cut-off values $<4.9\mu\text{m}^2$ and $>100\mu\text{m}^2$ in our case) in advance. So the capillaries that do not meet the requirements will be measured as zero.