


# ChemSusChem

## Supporting Information

### **Investigation of Voltage Range and Self-Discharge in Aqueous Zinc-Ion Hybrid Supercapacitors**


Jie Yang, Mark A. Bissett,\* and Robert A. W. Dryfe\*© 2021 The Authors. ChemSusChem published by Wiley-VCH GmbH. This is an open access article under the terms of the Creative Commons Attribution License, which permits use, distribution and reproduction in any medium, provided the original work is properly cited.

## SUPPORTING INFORMATION




**Figure S1.** Ionic conductivities of ZnSO<sub>4</sub> measured for the concentrations used in this study.

## SUPPORTING INFORMATION




**Figure S2.** Conductive carbon black (Super P): (a) Nitrogen physisorption isotherms and (b) NLDFT-derived pore size distribution.




**Figure S3.** Fabricated electrode using the activated carbon (YEC-8A) as active materials: (a) Nitrogen physisorption isotherms and (b) NLDFT-derived pore size distribution.

## SUPPORTING INFORMATION




**Figure S4.** Activated charcoal (C9157): (a) Nitrogen physisorption isotherms and (b) NLDFT-derived pore size distribution.

## SUPPORTING INFORMATION




**Figure S5.** Representative galvanostatic charge-discharge profiles of zinc ion hybrid supercapacitors based on activated charcoal (C9157).




**Figure S6.** Specific capacitances of activated charcoal (C9157) at various current densities


## SUPPORTING INFORMATION



**Figure S7.** Fitting of self-discharge process based on ohmic leakage model.




**Figure S8.** Fitting of self-discharge process based on ion diffusion model.



**Figure S9.** Fitting of self-discharge behavior based on faradaic process.


## SUPPORTING INFORMATION



**Figure S10.** SEM images of the AC electrode (a) before and (b) after cycling.

### Potential conversion

The standard redox potential of  $\text{Zn}^{2+}/\text{Zn}$  is as follows:



The practical concentration of  $\text{Zn}^{2+}$  is  $2 \text{ mol L}^{-1}$ . According to the Nernst equation, the practical potential of  $\text{Zn}^{2+}/\text{Zn}$  can be calculated as following:

$$E = E^\circ - \frac{RT}{nF} \ln \frac{[\text{Zn}]}{[\text{Zn}^{2+}]} = -0.762 - \frac{8.314 \times 298.15}{2 \times 96485} \times \ln \frac{1}{2} = -0.754 \text{ V (vs. SHE)}$$

The standard potential of reference electrode (Ag/AgCl with saturated KCl solution) is  $0.222 \text{ V (vs. SHE)}$ . Therefore, the required theoretical potential of  $(\text{Zn}^{2+}/\text{Zn})$  relative to the reference electrode (Ag/AgCl) is estimated to be  $-0.976 \text{ V (Vs. Ag/AgCl)}$ . This value is consistent with the experimentally obtained values.



## SUPPORTING INFORMATION

### Calculation of energy density and power density

Generally, the energy density of supercapacitors can be estimated by numerically integrating the discharge curves:<sup>[1]</sup>

$$E = \int_{t_1}^{t_2} IV dt \quad (1)$$

Where  $t_1$  and  $t_2$  are time,  $I$  is the current density,  $V$  is the discharge voltage.

If  $V$  is a linear function of time  $t$ , then

$$E = \int_{t_1}^{t_2} IV dt = \frac{1}{2} C (V_2^2 - V_1^2) \quad (2)$$

where  $V_1$  is minimum voltage at time  $t_1$ ,  $V_2$  is maximum voltage at time  $t_2$  and  $C$  is the capacitance of the device.


If  $V_1$  is set to be 0 V which is the common minimum voltage in symmetric supercapacitors, then equation (2) can be transformed into the most common equation widely used to calculate energy density in supercapacitors,

$$E = \frac{1}{2} C V_2^2 = \frac{1}{2} C \Delta V^2$$

Where  $\Delta V$  is the voltage window ( $\Delta V = V_2 - V_1$ ).

However, in the case of a hybrid supercapacitor, the minimum voltage  $V_1$  for capacitive behavior is usually larger than 0 V. Therefore, the equation (2) is used to calculate the corresponding energy density. It should be noted that the voltage does not display an ideal linear dependence on time in hybrid supercapacitors. If the equation is directly used to calculate the energy density in a hybrid device, the corresponding energy density will be overestimated. Therefore, direct numerical integration of the discharge curves is recommended. The differences between these two methods are compared below.

## SUPPORTING INFORMATION



**Figure S11.** The typical discharge curve of zinc ion hybrid supercapacitor at  $0.5 \text{ A g}^{-1}$

The energy density ( $E$ ) is calculated by using the following equation:

$$E = \int_0^{\Delta t} V(t) I dt = A_S I$$

Where  $\Delta t$  is the discharge time,  $V(t)$  is the voltage,  $I$  is the current density,  $A_S$  is the integral area denoted in the red area.

The energy density ( $P$ ) is calculated by:

$$P = \frac{E}{\Delta t}$$

## SUPPORTING INFORMATION

Table S1. Comparison of two methods to calculate the energy densities and power densities

Direct integral		Formula method	
$E = \int_{t_1}^{t_2} IV dt$		$E = \frac{1}{2} C (V_2^2 - V_1^2)$	
Energy density (Wh kg <sup>-1</sup> )	Power density (W kg <sup>-1</sup> )	Energy density (Wh kg <sup>-1</sup> )	Power density (W kg <sup>-1</sup> )
104.8	383.5	136.7	500
96.4	785.6	122.7	1000
85.6	1575.2	108.6	2000
78.7	2358.0	100.2	3000
69.0	3869.7	89.1	5000
63.5	6147.9	82.7	8000
58.7	7549.6	77.7	10000

## References:

- [1] Y. Wang, Y. Song, Y. Xia, *Chem Soc Rev* **2016**, *45*, 5925-5950.